
# Labwork


## In cisco packet tracer:

Step 1: First of all, add switch and 8 PCs around a switch. 8 PCs are:

- PC 0 and 1 is for Computer Department.
- PC 2 and 3 is for Civil Department.
- PC 4 and 5 is for Electronics Department.
- PC 6 and 7 is for Administrator Department.




**Step 2:** Connect all PCs in switch with help of copper straight through wire by selecting 'FastEthernet' in switch and PCs.



**Step 3:** Click on 'Desktop' option and go to IP Configuration. Select static and set IP address and subnet. Do this process all PCs.

#### For PC0:




#### For PC1:




#### For PC2:




#### For PC3:




## For PC4:




#### For PC5:



#### For PC6:



### For PC7:



**Step 4:** Go to command prompt and ping the IP address.

```
C:\>ping 202.50.70.126

Pinging 202.50.70.126 with 32 bytes of data:

Reply from 202.50.70.126: bytes=32 time<lms TTL=128
Ping statistics for 202.50.70.126:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 0ms, Average = 0ms</pre>
```

```
C:\>ping 202.50.70.224

Pinging 202.50.70.224 with 32 bytes of data:

Request timed out.

Ping statistics for 202.50.70.224:

Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
```